



**KU Air Handler**

**KD Air Handler**

# KU Air handler



## **KU24UH2I**

EHH21422700-5KW

EHH21421600-8KW

## **KU36UH2I**

EHH21422700-5KW

EHH21421600-8KW

EHH21421601-10KW

EHH21421700-15KW\*

## **KU48UH2I**

EHH21421601-10KW

EHH21421700-15KW

EHH21422800-20KW

## **KU60UH2I**

EHH21421601-10KW

EHH21421700-15KW

EHH21422800-20KW

\* 15KW with KU36UH2I required speed 5.

# KD Air Handler



## **KD24UHI**

BLR-5KW

BLR-8KW

## **KD30UHI**

BLR-5KW

BLR-8KW

## **KD36UHI**

BLR-5KW

BLR-8KW

BLR-10KW

## **KD42UHI**

BLR-5KW

BLR-8KW

BLR-10KW

## **KD48UHI**

BLR-5KW

BLR-8KW

BLR-10KW

BLR-15KW

BLR-20KW

## **KD60UHI**

BLR-5KW

BLR-8KW

BLR-10KW

BLR-15KW

BLR-20KW

Duct heater	Watts/Voltage	Max Breaker	Single point
5 KW	5000/240	30 amp	No
8 KW	8000/240	45 amp	No
10 KW	10000/240	60 amp	No
15 KW	15000/240	80 amp	Yes*
20 KW	20000/240	125 amp	Yes*



\* QOU14100JBAF

If not used, 2 separate wire must come from the panel.

15kw = 30 amp + 60 amp

20kw = 60 amp + 60 amp